



9 MAXM

2




3





7 x6 pcs

4




5

9 MAXM






6





7


9 MAXM



8




PA




3A MAXM (x3)

9 MAXM




3A MAXM(x3)


9 MAXM



utensili necessari
outils nécessaires
tools required




CC



6

DA




6

QL




3

QM




3

VJ




12

VA




6

VZ




12

SB



3




NOTES



Instructions






1



8 x3 pcs

3A MAXM

2



9/6/3 MAXM

(IT) Le ante possono andare in qualsiasi spazio

(FR) Les portes peuvent aller à tout espace

(EN) The doors can go to any space

3

