







K73 Desk



B120/140/160/180 A-PK

V 6/22


BZ



M6

8

WL



6

1

(IT) **Usare il prodotto in modo corretto**, esclusivamente per la funzione a cui è destinato.
Per spostarlo, sollevare e non trascinare.

(FR) **Utilisez le produit correctement**, exclusivement pour la fonction à laquelle il est destiné.
Pour le déplacer, soulevez et ne traînez pas.


(EN) **Use the product correctly**, exclusively for the function for which it is intended.
To move it, lift and not drag.

B120 A-PK L=120 CM


B140 A-PK L=140 CM

B160 A-PK L=160 CM

B180 A-PK L=180 CM




B 120/140/160/180 A-PK





K3

Gambe / Pietéments / Legs




BENCH x2



K3 Bench X2
+
15020 Panneau écran
+
KA1

BENCH x4



K3 Bench x4
+
15020 Panneau écran
+
KA1